

Karate Champ Player vs Player High Score Save Kit



Installation Instructions

Features

- 1. Saves High Score Table ***
- 2. Attract mode on during Coin / Free Play**

*** To clear the high score table hold down Player 1 + Player 2 start while the game is booting up**

Step 1

Remove the high score save kit from the package



Step 2

Carefully remove the eprom labeled BS19 HS with a flat head screw driver. Be careful not to bend the pins on the bottom while holding it.




Step 3

Remove the PCB from the cabinet




Step 4

Remove the z80 (outlined in blue) and remove eprom BS19 (outlined in red). The remaining eproms must remain in place and NOT removed like other kits.



Step 5

Place the z80 on to the HSS Kit. Make sure no pins get bent and the notch is facing the correct direction



Step 6

Place the HSS kit into the empty z80 socket.

Place BS19 HS in the empty eprom socket.

It should look like the picture below.



Step 7

Double check that no pins got bent and return the pcb to the cabinet. If you run into issues, double check that the eprom and z80 are facing the correct direction. Also double check that you are getting a strong +5 voltage (measure at the eprom on the HSS kit.